

# NEROLAC

## SATIN ENAMEL

SMOOTH FINISH

#### PRODUCT DESCRIPTION

Nerolac Satin Enamel is specially formulated to give an excellent smooth finish, resembling the smoothness of Satin to masonry, wood and metal surfaces. It can be easily cleaned to give a new look to the surface.

## PERFORMANCE FEATURES & BENEFITS



## SURFACE PREPARATION



## RECOMMENDED USAGE

It is specially recommended for all Suitably primed masonry, wooden and metal surfaces.

## APPLICATION



Sand the surface with Emery Paper and wipe clean before application on subsequent coats.

\*Nerolac Cement Primer (Solvent Thinnable) or Goody Universal Primer (Solvent Thinnable).

^Nerolac Red Oxide Metal Primer/ Goody Red Oxide Metal Primer/ Nerolac Syn.Primer Surfacer and Brushing Filler.

• Nerolac Wood Primer, White or Pink.

# Air Dry min. 8 Hrs. for dry scuff & min. 16-18 Hrs. for wet scuff. In case of stoving, give flash off 30 minutes. Stoving schedule is 30 minutes at 100°C.

For hassle free painting dial 1800 2092092 or sms NEROLAC to 54646

01



\*\*Actual coverage may vary depending on method, condition of application, surface roughness & shade.

### PRECAUTIONS

- Refer PDS for 'Nerolac Satin Enamel' for safety measures and precautions.
- Store in well ambient conditions, ventilated locations and away from sources of ignition and fire.
- Keep away from children.
- In case of eye/ skin contact, wash with plenty of water.
- Inhalation / Injection will cause danger. In case move to fresh air & consult medical practitioners in both the cases.
- Do not apply when ambient temperature might drop to level below 10°C within 4 Hrs. of application.
- New plaster should be allowed to cure for minimum 12 weeks.
- Avoid extra thinning for better results.
- Can be tinted with 'Nerolac Hi-Power Universal Stainer' before thinning. Do not add more than 5% of 'Nerolac Hi-Power Universal Stainer'. Stir the tinted paint well, after tinting & before application.
- The container must be tightly closed when not in use. Stir well and strain before use.
- Use safety equipment's like rubber or polythene gloves, safety goggles / glasses and face mask.

#### **POST APPLICATION INSTRUCTIONS** For removing stains sponge clean with a mild soap solution and wipe clean. Ensure a drying time of 1 week before cleaning.





SHADE RANGE As per Standard Nerolac Enamel Shade Cards and Colour Scapes Fandeck.

02 -